

Subprimo - Fitting Instructions

SubPrimo Installation

SubPrimo is supplied in 1150 x 950 x 6mm sheets, and is simply loose laid onto the existing floor in a brick pattern. SubPrimo can easily be cut and shaped using a standard trimming knife. It is important to ensure that the SubPrimo is installed tight up to or, if possible, under the skirting and that no gaps occur between the sheets as they are installed. The timber floor finish is then installed directly onto the SubPrimo, as with conventional underlays. It is important to leave an expansion gap between any timber floor finish and the perimeter. Direct contact between the floor finish and the beading or skirting should be avoided. The skirting board should sit on a length of SRS Soundseal acoustic sealing gasket - grade 15 2/10. The Soundseal will help isolate the floor from the wall construction. As with all floating floor installations, no fixings should be allowed to penetrate the resilient layer.

